Consumer Cellular®

Consumer Cellular.com

© 2026 Consumer Cellular, Inc. Consumer Cellular and the Consumer Cellular logo are trademarks of Consumer Cellular, Inc. The Bluetooth wordmark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks is under license. Other trademarks and trade names are the property of their respective owners.

IRIS TAB

QUICK START GUIDE



Consumer Cellular®

Welcome!

This guide will help you get the most out of your new IRIS Tab. You will find instructions to help you begin using your device.

If you ever need a little extra help, please don't hesitate to reach out. You can find our contact information on the last page.


We are always here and happy to assist you.

WHAT'S IN THE BOX

When you open the package, the box contains the following items:

- IRIS Tab
- USB-C charging cable
- 10-watt USB-C charger
- SIM tool
- Quick start guide
- Safety precautions guide

GETTING TO KNOW YOUR PHOHE



SETTING UP YOUR TABLET



Initial Setup

Power on your IRIS Tab.

1.Language & Vision settings

2.Setup using another device

3.Connect to mobile network

4.Connect to Wi-Fi

5.Sign in to your Google Acco

6.Create a security PIN

7.Contacts & Quick Share

8.Google Pay set up

9.Google services acknowledgement

10.Home screen layout


- Easy View or Classic View

NOTE: Your setup may be slightly different than the instructions in this Quick Start Guide due to software updates, or option choices.

INSTALLING A MEMORY CARD AND SIM CARD (OPTIONAL)

1. Insert the SIM pin provided to eject the SIM/memory card tray and then gently slide it out.
2. Insert the microSD™ card into the slot as shown.
3. If you are using a physical SIM, insert into the SIM slot.

NOTE: The IRIS Tab is compatible with a microSD™ memory card up to 512GB.



CHARGING YOUR TABLET

The tablet’s battery comes partially charged. After initial setup, charge your tablet's battery until fully charged.

IMPORTANT!

Use only approved chargers and USB cables.



Plug the cable into the tablet and wall charger, then into a wall outlet.


EASY VIEW VS CLASSIC ANDROID VIEW

Your device comes with the Easy View Experience by default. It is a simplified mobile interface designed for enhanced accessibility and ease of use. Ideal for users who prefer straightforward navigation.

Nothing is permanent here, change to either view when you want.


Featuring:


- Large, clearly labeled icons.
- Less clutter, easier to read.



HOME SCREEN SETTINGS

You can add, remove, or reorder home screen applications.





CHANGE TO CLASSIC ANDROID VIEW

Tap Settings > View All Settings >Display > Default home app > Android Experience

CONNECTING TO NETWORKS AND DEVICES

Connecting to Wi-Fi

1. Go to the IRIS Tab Settings.
2. Tap Network & internet.
3. Tap Internet, then tap the WIFI network name from the list. Enter the WIFI password and tap Connect.

Connecting to Bluetooth Devices

1. Go to your tablet's Settings and then Connected Devices.
2. Tap Pair new device to see Bluetooth devices around you.
3. Tap the device name from the list to connect.

PERSONALIZE YOUR TABLET

Increase or decrease the font size.

1. Tap Settings > Accessibility > Display size and text.
2. Tap Font size. To increase or decrease the font size, drag the font size level slider.


Use the notification panel.

When you receive new notifications, such as messages, icons appear at the top of the screen.

- To see more information about the notifications, swipe down from the top of the screen. To close the view, swipe up on the screen.
- To change the notification settings of an app, tap Settings > Notifications > App notifications, tap the application name to change the settings.

MESSAGES


IRIS Tab supports message synchronization. Setup your Google account on both devices and pair with your tablet. After pairing, the tablet receives and displays messages synced from your tablet.



CAMERA

How do I take a picture?

1. On the Home screen, tap .
2. Aim the camera at the subject and make any necessary adjustment.
3. Lightly tap to take the picture.



WHAT DO I DO IF I GET STUCK?

Visit our website www.consumercellular.com/Device-Support/Consumer-Cellular or scan the QR code below using your tablet's camera.

Call us at (888) 345-5509 for additional support.

Scan the QR code with your tablet's camera to open a link to our support page.

