

Balance Your World



Quick Start Guide

Welcome to the Nokia 1600 phone!

Thank you for purchasing the Nokia 1600 phone. This Quick Start Guide will help you get started with your new phone quickly and easily. This guide covers the basics only. To learn more about other great features of your Nokia 1600 phone, as well as important safety and operating information, please review the user guide or visit www.nokiausa.com.

NOKIA
1600

9248621. Printed in Mexico.
All screen images are simulated.

NOKIA
Connecting People

1 Learn about parts of the phone

- 1 **High-definition up to 65,536 color screen** – Easy-to-read screen
- 2 **Signal strength indicator** – Indicates the signal intensity of the cellular network
- 3 **Battery level indicator** – Indicates the current battery charge level
- 4 **Left and right selection keys** – Function depends on the text shown on the display above them
- 5 **Scroll keys** – Used to navigate through menu items
- 6 **Call key** – Dials a phone number or answers a call
- 7 **End key** – Press and hold to switch the phone on or off; briefly press to end a call or exit a function
- 8 **Alarm key** – Press and hold to activate the speaking clock
- 9 **Charger connector** – Connect your charger here
- 10 **Headset jack** – Connect your headset connections here



2 Install the SIM card and battery

Your Nokia 1600 phone uses a convenient **SIM card** that holds information about your wireless service and contact information. If you already have a SIM card, you can transfer your service and contacts to your new phone by simply inserting the SIM. If you do not have a SIM or service for the phone, contact your wireless provider.


The Nokia BL-5C battery provides power in a lightweight package. A fully charged battery has up to 5 hours 30 minutes of talk time and up to 18 days of standby time*.

*Talk and standby times are estimates and vary based on many factors. For complete information and a list of major factors impacting these times, please refer to www.nokia.com/us

Inserting the SIM card

Follow the instructions below if your phone displays “Insert SIM card”.

1. Turn off the phone.
2. Press the back cover release button, open the back cover, and remove it (fig 3.1).
3. Remove the battery (fig 3.2).
4. Carefully lift the SIM cardholder (fig 3.3).
5. Insert the SIM card into the slot. Ensure that the gold-colored contact area on the card is facing downward. Then, close the SIM cardholder, and press it to lock it into place (fig 3.4).
6. Slide the battery into the back of the phone (fig 3.5).
7. Align the cover on the back of the phone and push gently into position.



3 Easy to use ... make life easier

Straightforward and simple, the Nokia 1600 phone makes life easier for its owner. It has an intuitive icon-based interface, a high-definition color display, a graphical demo mode, and a handsfree speaker. The Nokia 1600 phone enables you to personalize your contacts view. By setting an icon as a contact, you'll know instantly who's calling!

Set an icon as a contact

1. Press the left selection key to select Menu. (—)
2. Scroll to and select Contacts. (□) (—)
3. Scroll to and select Add name. (□) (—)
4. Enter the contact name using the keypad and select OK (fig 4.1). (—)
5. Enter the phone number using the keypad and select OK (fig 4.2). (—)
6. Scroll to select the contact icon you want to assign and then select Insert (fig 4.3). (□) (—)




fig 4.1




fig 4.2




fig 4.3

4 Clock ... make time for life

With the many demands of daily life, it's easy to lose track of time. But help is at hand. The Nokia 1600 phone with its reminders, alarm, and speaking clock will keep you on track and on time. Set the speaking clock to your language and have the time spoken to you when you need to know it.

Setting the speaking clock

1. Press the left selection key to access the Menu. (—)
2. Scroll to and select Clock (fig 5.1). (□) (—)
3. Scroll to and select Speaking clock (fig 5.2). (□) (—)
4. Press Select to activate the speaking clock (fig 5.3). (—)




fig 5.1




fig 5.2



fig 5.3

5 Get support and enjoy!

Nokia's support options are designed to be flexible and comprehensive. Nokia has the right solutions to meet your needs.

Nokia 1600 User Guide

The User Guide offers you the most comprehensive detail on how to use your new Nokia 1600 phone.

Nokia Support on the Web

Check www.nokiausa.com/support for the latest information to help you to get the most from your Nokia 1600 phone.

1-888-NOKIA-2U (1-888-665-4228)

Nokia provides toll-free customer support, Monday–Friday from 8.00 a.m. to 12.00 noon EST and Saturday–Sunday from 10.00 a.m. to 7.00 p.m. EST.

Service Provider

Contact your service provider for questions regarding your wireless service.

